

# **Nick Grinder Information**

## **About the nick grinder**

The nick grinder is designed with the purpose of creating cuts and nicks into creasing rules and perforation blades.

There are 3 different type of nick grinder available which are

- Pneumatic
- Electric
- Battery

All 3 types are completely portable, this means that they can be used in any situation.

## **How to use the nick grinder**

### **Mounting the grinding wheel**

- Remove the protective guard
- Place tommy bar inside the hole in the main spindle
- Use an allen key to tighten the clamp via the flange nut.
- Re-fit the protective guard

### **Setting the depth of the nick**

- By using the screw on top of the main body this will change the depth

## **Safety information**

Power supply must be disconnected before any settings are changed.

- Pneumatic – Air supply removed
- Electric – Power switched off
- Battery – Motor switched off

Safety clothing must be worn when operating the nick grinder.

Protective eyewear must be worn when operating the nick grinder

Ensure that the protective guard is in place before connecting the nick grinder with a power source.

## **Recommendations**

We advise that the user of the nick grinder should use 2 hands when operating the unit. This gives more stability which results in a cleaner cut.

## **Equipment supplied**

Nick Grinder  
Suitable allen key  
Tommy bar

## **Optional extra's available**

European adaptor plug for electric motors  
Spare batteries for battery units